

POLI-TAPE® 2 SUBLI

	SUBLIMATION			TRANSFER				WASHER	COTTON	POLYESTER	POLYESTER / COTTON	POLYESTER / ACRYLIC	SUBLIMATED POLYESTER	UNCOATED NYLON APPLICATION TEST REQUIRED
	TEMPERATURE	TIME	PRESSURE	TEMPERATURE	TIME	PRESSURE	IRON							
POLI-TAPE® SUBLI UP	/	/	/	140° C	15 SEC	MEDIUM 3.0 BAR	POLI-TACK 8031 COLD	30° C	●	●	●	●		150° C 20 SEC
POLI-TAPE® SUBLI UP PATCH	190° C	30 SEC	MEDIUM 3.0 BAR	160° C	15 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	40° C	●	●	●	●		●
POLI-PATCH	190° C	50 SEC	MEDIUM 3.0 BAR	150° C	20 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	60° C*	●	●	●	●		●
POLI-PATCH SOFT	190° C	50 SEC	MEDIUM 3.0 BAR	150° C	20 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	60° C*	●	●	●	●		●
POLI-PATCH BLOCKSUB	190° C	50 SEC	MEDIUM 3.0 BAR	140° C	10 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	40° C	150° C 20 SEC	150° C 20 SEC	150° C 20 SEC	150° C 20 SEC	●	150° C 20 SEC
POLI-FLEX® 4675	190° C	50 SEC	MEDIUM 3.0 BAR	160° C	15 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	90° C TD / DC	●	●	●	●		
SUBLI-FLOCK 5901 / 5902	190° C	50 SEC	LOW 2.0 BAR	160° C	15 SEC	MEDIUM 3.0 BAR	POLI-TACK 850 WARM	60° C TD / DC	●	●	●	●		

TD = TUMBLE DRY

DC = DRY CLEANING

*ON NYLON TEXTILES: ONLY 40 °C

BEFORE APPLICATION / PRODUCTION WE RECOMMEND AN APPLICATION TEST ON YOUR GARMENT

